

**FOR OFF ROAD/RACE USE ONLY!**



**PART#: D5916/D5098/D5099 SPROCKET CARRIER  
INSTALLATION INSTRUCTIONS**

DRIVEN PERFORMANCE PRODUCTS  
WWW.DRIVENRACING.COM  
866-5-DRIVEN

**THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECH\***

1. Remove circular spring clip from drive shaft.
2. Remove drive nut from shaft.
3. Remove nuts from sprocket holder.
4. Remove sprocket from carrier.
5. Remove cush drive inserts.
6. Install DRIVEN sprocket onto carrier with part # facing away from carrier.
7. Install OEM cush drive inserts into DRIVEN carrier.
8. Using blue Loctite (#242) and supplied hardware secure sprocket to carrier and ensure the head of each stud in the carrier is seated correctly.\*
9. Make sure all OEM washers are in place and apply a thin layer of grease before carefully mounting carrier to driveshaft.
10. Install drive nut and torque to OEM specifications.
11. Install circular spring clip.

---

#### **TORQUE SPECS AND INFO**

- Carrier Sprocket Nuts (MAX 20 ft-lbs)
- Use blue Loctite (#242)\*

**USE BLUE LOCTITE ON ALL MOUNTING BOLTS!**

**FOR OFF ROAD/RACE USE ONLY!**



**PART#: D5916/D5098/D5099 SPROCKET CARRIER  
INSTALLATION INSTRUCTIONS**

DRIVEN PERFORMANCE PRODUCTS  
WWW.DRIVENRACING.COM  
866-5-DRIVEN

**THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECH\***

1. Remove circular spring clip from drive shaft.
2. Remove drive nut from shaft.
3. Remove nuts from sprocket holder.
4. Remove sprocket from carrier.
5. Remove cush drive inserts.
6. Install DRIVEN sprocket onto carrier with part # facing away from carrier.
7. Install OEM cush drive inserts into DRIVEN carrier.
8. Using blue Loctite (#242) and supplied hardware secure sprocket to carrier and ensure the head of each stud in the carrier is seated correctly.\*
9. Make sure all OEM washers are in place and apply a thin layer of grease before carefully mounting carrier to driveshaft.
10. Install drive nut and torque to OEM specifications.
11. Install circular spring clip.

---

#### **TORQUE SPECS AND INFO**

- Carrier Sprocket Nuts (MAX 20 ft-lbs)
- Use blue Loctite (#242)\*

**USE BLUE LOCTITE ON ALL MOUNTING BOLTS!**

