

FOR OFF ROAD/RACE USE ONLY!



D-AXIS M8 TO M6 REDUCER KIT

Part # DXSR-6

Installation Instructions

Tools Required

5mm Hex Key
flat screw driver

1. Instal m8to m6 reducer into swing arm using a flat screw driver(use blue loctite) fig 1
2. install M6 spool into reducer using an m5 allen key . (use blue loctite) fig 2

fig. 1



fig. 2



THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!

FOR OFF ROAD/RACE USE ONLY!



D-AXIS M8 TO M6 REDUCER KIT

Part # DXSR-6

Installation Instructions

Tools Required

5mm Hex Key
flat screw driver

1. Instal m8to m6 reducer into swing arm using a flat screw driver(use blue loctite) fig 1
2. install M6 spool into reducer using an m5 allen key . (use blue loctite) fig 2

fig. 1



fig. 2



THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!